Quick Tip:
When battery runs out, PixelWhip will blink red 3 times to indicate low power, then power off.

Turn On: Long-press for 1 second

Change Style: Long-press for 1 second

Change Channel: Short-press

Turn Off: Long-press for 2 seconds

STYLE 4

PULSING SWATCHES

Pattern Channel 1 — *Independence*




Pattern Channel 2 — *Firestorm*



Pattern Channel 3 — *Gem*



Pattern Channel 4 — *Jade*



Pattern Channel 5 — *Electricity*



Pattern Channel 6 — *Blizzard*



Pattern Channel 7 — *Twilight*



Pattern Channel 8 — *Raspberry Lime Sherbert*



Pattern Channel 9 — *Watermelon pulse*



Pattern Channel 10 — *Rainbow Unicorn*



STYLE 1

SINGLE COLORS

Pattern Channel 1 — *Red*




Pattern Channel 2 — *Orange*



Pattern Channel 3 — *Yellow*



Pattern Channel 4 — *Green*




Pattern Channel 5 — *Cyan*



Pattern Channel 6 — *Sky Blue*



Pattern Channel 7 — *Blue*



Pattern Channel 8 — *Purple*



Pattern Channel 9 — *Magenta*



Pattern Channel 10 — *White*



40 patterns organized into
10 channels in **4 styles**!

Quick Tip:
PixelWhip remembers the last color you were on, and resumes the next time you turn on!

STYLE 2

COLOR WIPES

Pattern Channel 1	Magenta/Red Wipe
Pattern Channel 2	Yellow/Red Wipe
Pattern Channel 3	Yellow/Green Wipe
Pattern Channel 4	Green/Blue Wipe
Pattern Channel 5	Cyan/Magenta Wipe
Pattern Channel 6	White/Blue Wipe
Pattern Channel 7	Blue/Magenta Wipe
Pattern Channel 8	Purple/Yellow Wipe
Pattern Channel 9	Watermelon Wipe
Pattern Channel 10	Rainbow Wipe

STYLE 3

TRIPLE COLORS

Pattern Channel 1	Red/White/Blue
Pattern Channel 2	Red/Yellow/White
Pattern Channel 3	Green/Yellow/Red
Pattern Channel 4	Yellow/Green/Blue
Pattern Channel 5	Cyan/Magenta/Yellow
Pattern Channel 6	Blue/Cyan/White
Pattern Channel 7	Blue/Yellow/Red
Pattern Channel 8	Purple/Yellow/Purple
Pattern Channel 9	Watermelon sandwich
Pattern Channel 10	Red/Green/Blue