



## ANTI-VIBRATION & DIFFUSION KIT

The anti-vibration and diffusion kit optimizes your tubing-based flowtoys by eliminating rattle and diffusing the light to a soft glow.

**Your kit comes with:**

- 2 sheets of diffusive mylar with adhesive
- 6 foam pucks

### INSTALLING DIFFUSIVE MYLAR:

Roll the mylar and insert it into the tube with adhesive side facing out, and at the cap end of the tube. Carefully remove the adhesive backing and fix the adhesive to the inside of the tube about 2mm below the lip of the tube. The flowcap can rip the mylar out if it's too close to the edge. Do not leave any mylar overhanging outside the tube, as this can interfere with proper operation of your cap.

### INSTALLING FOAM:

**Flowcaps:** Place one foam puck in the bottom of the tube, making sure to push it all the way to the connector/woodcore.

**Pod shells:** Place up to three foam pucks in the bottom of the tube, making sure to push them all the way to the connector/woodcore.

Reinstall your lights and you're ready for ultra-ninja-stealth flow!

2021.01



## ANTI-VIBRATION & DIFFUSION KIT

The anti-vibration and diffusion kit optimizes your tubing-based flowtoys by eliminating rattle and diffusing the light to a soft glow.

**Your kit comes with:**

- 2 sheets of diffusive mylar with adhesive
- 6 foam pucks

### INSTALLING DIFFUSIVE MYLAR:

Roll the mylar and insert it into the tube with adhesive side facing out, and at the cap end of the tube. Carefully remove the adhesive backing and fix the adhesive to the inside of the tube about 2mm below the lip of the tube. The flowcap can rip the mylar out if it's too close to the edge. Do not leave any mylar overhanging outside the tube, as this can interfere with proper operation of your cap.

### INSTALLING FOAM:

**Flowcaps:** Place one foam puck in the bottom of the tube, making sure to push it all the way to the connector/woodcore.

**Pod shells:** Place up to three foam pucks in the bottom of the tube, making sure to push them all the way to the connector/woodcore.

Reinstall your lights and you're ready for ultra-ninja-stealth flow!

2021.01



## ANTI-VIBRATION & DIFFUSION KIT

The anti-vibration and diffusion kit optimizes your tubing-based flowtoys by eliminating rattle and diffusing the light to a soft glow.

**Your kit comes with:**

- 2 sheets of diffusive mylar with adhesive
- 6 foam pucks

### INSTALLING DIFFUSIVE MYLAR:

Roll the mylar and insert it into the tube with adhesive side facing out, and at the cap end of the tube. Carefully remove the adhesive backing and fix the adhesive to the inside of the tube about 2mm below the lip of the tube. The flowcap can rip the mylar out if it's too close to the edge. Do not leave any mylar overhanging outside the tube, as this can interfere with proper operation of your cap.

### INSTALLING FOAM:

**Flowcaps:** Place one foam puck in the bottom of the tube, making sure to push it all the way to the connector/woodcore.

**Pod shells:** Place up to three foam pucks in the bottom of the tube, making sure to push them all the way to the connector/woodcore.

Reinstall your lights and you're ready for ultra-ninja-stealth flow!

2021.01



## ANTI-VIBRATION & DIFFUSION KIT

The anti-vibration and diffusion kit optimizes your tubing-based flowtoys by eliminating rattle and diffusing the light to a soft glow.

**Your kit comes with:**

- 2 sheets of diffusive mylar with adhesive
- 6 foam pucks

### INSTALLING DIFFUSIVE MYLAR:

Roll the mylar and insert it into the tube with adhesive side facing out, and at the cap end of the tube. Carefully remove the adhesive backing and fix the adhesive to the inside of the tube about 2mm below the lip of the tube. The flowcap can rip the mylar out if it's too close to the edge. Do not leave any mylar overhanging outside the tube, as this can interfere with proper operation of your cap.

### INSTALLING FOAM:

**Flowcaps:** Place one foam puck in the bottom of the tube, making sure to push it all the way to the connector/woodcore.

**Pod shells:** Place up to three foam pucks in the bottom of the tube, making sure to push them all the way to the connector/woodcore.

Reinstall your lights and you're ready for ultra-ninja-stealth flow!

2021.01