

Need podpoi support?

Sync your lights for wireless control, adjust your leashes, tips & troubleshooting.
Find these and more at: flowtoys.com/product-support/podpoi

SAFEGUARDS AND PRECAUTIONS

This guide outlines basic safeguards in using your flowtoys. The information presented cannot cover all possible circumstances that may occur. In using any flowtoy, the user understands that common sense and caution cannot be built into the product, and must be provided by him/herself. Please read all instructions before using your toys.

1. Flowtoys are intended for practice, play, performance and meditation. Do not use for any other purpose.
2. Do not use products under the influence of alcohol or drugs. Consult prescription labels to determine if a particular drug would impair your judgment or reflexes. If so, do not use this product.
3. Stay alert and use common sense. Do not use this product when tired or distracted. Be aware when in the presence of fragile or breakable objects.

BEFORE USE: Check for damaged parts before using any product. Ensure caps, connectors and battery doors are fully secured. Most flowtoys are made of individual pieces that can separate during use if not properly assembled.

GENERAL CARE: Repair or replace damaged or worn parts before use. Do not use damaged products.

REGULAR MAINTENANCE: Maintain all Flowtoys products with care. Store in a clean, dry environment. Avoid unnecessary exposure to sunlight: UV rays will weaken most plastics over time.

WARNING: This product is not intended for use by children age 14 and under.



WARNING! LITHIUM ION BATTERY SAFETY PRECAUTIONS

You must read these safety instructions and warnings before using or charging your batteries.

Capsule lights use rechargeable lithium ion batteries. Lithium ion batteries might cause damages like leaking, fire or explosion when misused or defective. Failure to read and follow the below instructions may result in fire, personal injury and damage to property if charged or used improperly or if defective. Please read carefully and be aware!

- Always charge in an isolated area, away from other flammable materials like wood or carpet. Never charge batteries unattended.
- Please double check your charger to assure it is operating correctly at the beginning of every charge cycle. If your charger or battery becomes hot, balloons/swells, emits smoke or smells unusual, **STOP CHARGING IMMEDIATELY**. Observe the battery for 15 minutes in a safe area outside of any building or vehicle and away from any combustible material to assure that it does not ignite, and contact us.
- Some microUSB chargers on the market may have technical deficiencies that may cause them to charge Li-ion batteries incorrectly or at an improper rate. It is your responsibility solely to assure the charger you purchased works properly. Always monitor charging process to assure batteries are being charged properly.
- Do NOT disassemble or modify the battery. Vibration, puncture, contact with metals, exposure to liquid or tampering with the battery can cause it to fail. The battery contains safety and protection devices, which, if damaged, may cause the battery to generate heat, explode, ignite, or short circuit. Severe injury may occur.
- Store in a cool, dry place. Never store or charge batteries in extreme temperatures, such as a hot car; near heat sources or fire; or in pressurized or very cold environments.
- Keep away from children.
- If the battery leaks and the fluid gets into your eye, do not rub your eye. Rinse well with water and immediately seek medical care. If left untreated, the battery fluid could cause damage to the eye.

FOREVER FLOW LIFETIME WARRANTY

Flowtoys are designed to last you a lifetime, but nothing is indestructible, so we provide this warranty to enable you to freely find your flow*.



If you manage to break a flowtoys product, we offer free replacements on defective or non-working parts due to intended use, and

50% credit for products in any condition at any time. Battery depletion is normal wear & tear and covered for free in first 2 years and half-price/capsule after.

If you need warranty support, please contact us at support@flowtoys.com.

* Please check flowtoys.com for full warranty details.

Flowtoys reserves the right to refuse coverage to anyone abusing this warranty. Please contact us before sending in your product, or it may be returned to sender.



Length: 118mm | Diameter: 66mm | Weight: 120g

Welcome to your podpoi - it comes with many incredible features and moments of joy. Simply press the button at the bottom to turn it on. That's all you need to start having a great time.

Check the flowOS pocket guide for more on operating your lights. These manuals have basic instructions - there are many more awesome tips and a quickstart video on our website. You are invited to check them out at: flowtoys.com/product-support/podpoi

POWER

Charging: There is a microUSB jack on the side of the capsule. No need to disassemble to charge --> Simply "squish" the pod by pressing down on the tri-ring and the bottom of the shell - look through the slits between the petals to reveal the charging jack. Charge w/ the provided cable.

Capsule light should turn on and begin "breathing" its charge-level color. When charging, the indicator light is not entirely accurate until done charging (green). If your light is NOT grouped, it will turn green when fully charged for a few minutes, then it will shut off to save power. The capsule light takes 3-4 hours to fully charge, but 90% of the charge happens in 2 hours.

Checking your battery charge level: From off, press and hold the button. The light will blink a color indicating your battery level - ranging from red to green - until you let go. Your battery may be low when you first receive your lights - if so, please charge before use.

Red <10% ... Orange ~50% ... Yellow 50-90% ... Green >90%

Note: Colors are approximate. Runtimes vary greatly with different modes.

Low battery mode & dead battery indicator: When the battery gets low, the capsule will exhibit a dim red flicker for awhile, so your light doesn't go totally dark immediately. If your light blinks red and turns off, the battery is totally out of juice. Time to plug in and recharge!

HARDWARE

Adjusting your leash length: A popular leash length is from your hand to your shoulder. Untie the knot at the knob, move knob to your desired length, tie a simple knot, ensure both of leashes are the same length before tightening the knot. Cut excess leash above the knot, and melt the end to make a melted puck, so the knot is secure.

Assembling the tri-ring back onto the pod: If your tri-ring comes loose, here's how to re-assemble it. Insert 2 petals into the tri-ring, position the leash, pinch the tip of the 3rd petal and push/massage it inside the tri-ring. **Pro tip:** align tips of the tri-ring with seams on the pod shells.